


INSTALLATION INSTRUCTION FOR CELLMAX-D-43-WI



Installation Steps

- 1.) Prepare the screw and plastic bolts so that they are fixed on the needed positions.
- 2.) To complete the installation, hang the antenna with its hanging plate into the mounting plate that is fixed to the wall.

Note:

Cable bending radius must not be less than 40 mm.

Online Support

Scan the QR code to submit tickets:



Copyright © 2026 ANDREW®, an Amphenol company. All Rights Reserved.

Amphenol and ANDREW are registered trademarks of Amphenol and/or its affiliates in the U.S. and other countries. All product names, trademarks and registered trademarks are property of their respective owners.

Andrew Wireless Systems GmbH, 26-March-2026