



Installation Instruction for CMAX-OUS1-UW43-I53



CMAX-OUS1-UW43-I53

Document Number: **M0153A8**

Document Revision: **01**

Date: **April 2026**

Copyright © 2026 ANDREW[®], an Amphenol company. All Rights Reserved.

This document has been developed by ANDREW, an Amphenol company, and is intended for the use of its customers and customer support personnel. The specifications and information regarding the products in this manual are subject to change without notice. All statements, information, and recommendations in this manual are believed to be accurate but are presented without warranty of any kind, express or implied. Users must take full responsibility for their application of any products.

The software license and limited warranty for the accompanying product are set forth in the information packet that shipped with the product and are incorporated herein by reference. If you are unable to locate the software license or limited warranty, contact your ANDREW sales representative for a copy.

Andrew Wireless Systems GmbH, 28-April-2026

TABLE OF CONTENTS

1. INSTALLATION	4
1.1. INSTALLATION PREPARATIONS	4
1.2. INSTALLATION PROCEDURES	4
1.2.1. Method 1	4
1.2.2. Method 2	5
2. CONTACTING ANDREW	6
2.1. TECHNICAL SUPPORT	6
2.2. WASTE ELECTRICAL AND ELECTRONIC EQUIPMENT RECYCLING	6
2.3. TECHNICAL TRAINING	7
2.4. ACCESSING USER DOCUMENTATION	7

LIST OF CHANGES

Version	Changes	Release Date
M0153A8A		18-May-2020
M0153A8B	<ul style="list-style-type: none">- Branding and contact information updated- Obsolete version deleted- Bending radius information enhanced	28-April-2026


1. Installation

1.1. Installation Preparations

- Please read the complete description before starting the installation.
- Observe that the bending radius of the cables must not be less than 40 mm.
- For optimal operation, this antenna should **NOT** be mounted to a **metallic ceiling/surface**. If there is no other option, contact our Technical Support (see chapter 2.1).

1.2. Installation Procedures


1.2.1. Method 1



Installation Steps

- 1) Cut a hole in the ceiling tile with the diameter shown above.
- 2) Remove the retaining nut from the back of the antenna.
- 3) Feed the pigtail of this antenna through the hole in the ceiling tile.
- 4) Re-install the retaining nut so that it is close-fitting to the ceiling tile.

1.2.2. Method 2



Installation Steps

- 1) Position and drill three screw holes of specified size.
- 2) Put plastic expansion pins in the holes first.
- 3) Feed the pigtail of this antenna through the hole in the ceiling tile.
- 4) Use 4*25 self-tapping screws to lock the antenna to the ceiling according to the corresponding hole position.
- 5) In case you want to cover the screw holes, suitable covers are available.

2. Contacting ANDREW

The following sections tell you how to contact ANDREW® for additional information or for assistance.

2.1. Technical Support

This section tells you how to contact the ANDREW Technical Support team. Support is available 7 days a week, 24 hours a day.

Telephone Helplines

Use the following Helpline telephone numbers to get live support, 24 hours a day.

24X7 +1 888-297-6433 (Toll free for U.S. and Canada)
EMEA 8:00-17:00 (UTC +1) + 800 73732837 (Toll free for parts of EMEA and Australia)
+ 49 909969333 (Toll charge incurred)

Calls to an EMEA Helpline outside of the 8:00 to 17:00 time frame will be forwarded to the 24x7 Helpline.

Online Support

Click the link below or scan the QR code to the right to submit tickets using the online [Technical Support Form](#).



2.2. Waste Electrical and Electronic Equipment Recycling

In alignment with our commitment to the Waste Electrical and Electronic Equipment (WEEE) Directive, we design and manufacture our products with sustainability as a priority. We are dedicated to supporting responsible end-of-life disposal and recycling practices, which help reduce environmental impact and promote a circular economy.

To learn more, scan the QR code to the right or click the link below:

<https://www.andrew.com/sustainability/environment/weee/>



2.3. Technical Training

1. To access training on the online technical training site, please click <https://www.andrew.com/support/training/> or scan the QR code to the right:
2. From here you can see course catalogs, training calendars, and visit the training portal that lets you register for online and instructor-led courses and take online courses.
3. Instructor-led courses are conducted in North America and Europe. Before choosing a course, please verify the region.
4. For training related questions, please contact us: icn_training@andrew.com



2.4. Accessing User Documentation

1. Access to the Customer Portal requires a user account. If you don't have an account:
 - Visit My ANDREW at <https://www.andrew.com/membership> or by scanning the QR code to the right.
 - Click “New user registration” and follow the prompts.
 - After you have registered in My ANDREW, click the **Request access** button for the **Customer Portals**.
 - After having done the request, it might take several days to get approved. Then, you can select the **Indoor Wireless Resource Center for ANDREW** from the list of applications.
2. To go directly to the portal, where you can access the DAS-user documentation, scan the QR Code to the right.
Alternatively, visit My ANDREW (see above) and use the **Indoor Wireless Resource Center for ANDREW** application.
3. In Tools and Documentation, search by product, document category, or title.
4. Click on the title of any document to open it.

